

## ATT-7 Operating and Maintenance Plan

The Baghouse is maintained by:

- Monitor the pressure gauge during operation to make sure it is within limits. Limits are within range of 3" to 5" WC
- Visually inspect stack periodically when operating
- If a problem occurs
  - Check bags for signs of damage or slipped bags
  - Use visolite dust to locate defective bag(s)
  - Replace any defective bags when needed and replace bags approximately every three to five years. (Depending upon tonnage processed)