

ATT-8

Start-up & Shutdown

Start-up:

- 1) Turn on shaker and hot elevator
- 2) Turn on Baghouse fan
- 3) Turn on dust screw, air valve and small fan on the baghouse. (Baghouse is now on.)
- 4) Turn on fire fan on the drum
- 5) Wait a few minutes and light burner
- 6) Start rotary dryer rotation
- 7) Turn rotary chute on located at back off dryer
- 8) Turn cold feed elevator on
- 9) Turn dirt bins on, which includes the belts

READY TO MIX ASPHALT

Shutdow:

- 1) Turn dirt bins off
- 2) Turn cold feed off
- 3) Turn rotary chute off
- 4) Turn dryer and burner off at the same time
- 5) Turn fire fan off
- 6) Let baghouse run for a few minutes to cool down bags and pump dirt from bags
- 7) Turn off baghouse fan
- 8) Turnoff shaker and hot elevator