HUMAN CREMATORY AIR GENERAL PERMIT REGISTRATION FORM

Part II. Notification to Permitting Office

(Detach and submit to appropriate permitting office; keep copy onsite)

Instructions: To give notice to the Department of an eligible facility's intent to use this air general permit, the owner or operator of the facility must detach and complete this part of the Air General Permit Registration Form and submit it to the appropriate Department of Environmental Protection or local air pollution control program office which has permitting authority. Please type or print clearly all information, and enclose the appropriate air general permit registration processing fee pursuant to Rule 62-4.050(4)(0), F.A.C. (\$100 as of the effective date of this form)

Registration Type /0/0365-009
Check one:
 INITIAL REGISTRATION - Notification of intent to: Construct and operate a proposed new facility. Operate an existing facility not currently using an air general permit (e.g., a facility proposing to go from an air operation permit to an air general permit).
RE-REGISTRATION (for facilities currently using an air general permit) - Notification of intent to: ☐ Continue operating the facility after expiration of the current term of air general permit use. ☐ Continue operating the facility after a change of ownership. ☐ Make an equipment change requiring re-registration pursuant to Rule 62-210.310(2)(e), F.A.C., or any other change not considered an administrative correction under Rule 62-210.310(2)(d), F.A.C.
Surrender of Existing Air Operation Permit(s) - For Initial Registrations Only
If the facility currently holds one or more air operation permits, such permit(s) must be surrendered by the owner or operator upon the effective date of this air general permit. In such case, check the first box, and indicate the operation permits being surrendered. If no air operation permits are held by the facility, check the second box.
All existing air operation permits for this facility are hereby surrendered upon the effective date of this air general permit; specifically permit number(s):
No air operation permits currently exist for this facility.
General Facility Information
Facility Owner/Company Name (Name of corporation, agency, or individual owner who or which owns, leases, operates, controls, or supervises the facility.) TRINITY MEMORIAL CEMETARY, INC.
Site Name (Name, if any, of the facility site; e.g., Plant A, Metropolis Plant, etc. If more than one facility is owned, a registration form must be completed for each.) D.B.A. TRINITY MEMORIAL GARDENS
<u>Facility Location</u> (Provide the physical location of the facility, not necessarily the mailing address.) Street Address: 12609 MEMORIAL DR.
City: NEW PORT RICHEY County: PASCO Zip Code: 34655
Facility Start-Up Date (Estimated start-up date of proposed new facility.) (N/A for existing facility) N/A


DEP Form No. 62-210.920(2)(c) Effective: January 10, 2007

Owner/Authorized Representative					
Name and Position Title (Person who, by signing this form below, certifies that the facility is eligible to use this					
air general permit.)					
Print Name and Title: LISA SOMMERS, GENERAL MANAGER					
O Andrei I Demonstration Mailine					
Owner/Authorized Representative Mailing organization/Firm: TRINITY MEMORIA		~			
Street Address: 12609 MEMORIAL DR.	- CLINE FART, IN	J.			
City: NEW PORT RICHEY	County: PASCO		Zip Code: 34655		
			2.6 0000.		
Owner/Authorized Representative Telephone Numbers					
Telephone: 727-376-7824	Fax: 727-376-7744				
Cell phone (optional):					
		F: 5	and the second s		
Facility Contact (If different from Owner/Authorized Representative) Name and Position Title (Plant manager or person to be contacted regarding day-to-day operations at the facility.)					
Name and Position Title (Plant manager or Print Name and Title: SAME AS ABOVE	person to be contact	ed regarding day-	to-day operations at the facility.)		
Print Name and Title: SAME AS ABOVE					
Facility Contact Mailing Address					
Organization/Firm:					
Street Address:					
City:	County:		Zip Code:		
			•		
Facility Contact Telephone Numbers					
Telephone:	F	Fax:			
Cell phone (optional):					
Owner/Authorized Representative States	ment				
This statement must be signed and dated by	-		•		
I, the undersigned, am the owner or au					
addressed in this Air General Permit Registration Form. I hereby certify, based on information and belief formed after reasonable inquiry, that the facility addressed in this registration form is eligible for					
use of this air general permit and that the statements made in this registration form are true, accurate					
and complete. Further, I agree to operate and maintain the facility described in this registration form so					
as to comply with all applicable standards for control of air pollutant emissions found in the statutes of					
the State of Florida and rules of the Department of Environmental Protection and revisions thereof.					
inc crane by the rank and three by the 2 of	, , - ,		· · · · · · · · · · · · · · · · · · ·		
I will promptly notify the Department o	f any changes to the	information cont	ained in this registration		
form.	-				
_					
· <		1			
hisa Jonners		<u> </u>	24/09		
Signature		Date	•		

DEP Form No. 62-210.920(2)(c) Effective: January 10, 2007

Design Calculations
If this is an initial registration for a proposed new human crematory unit, provide design calculations to confirm a sufficient volume in the secondary chamber combustion zone to provide for at least a 1.0 second gas residence time at 1800 degrees F.
Manufacturer's' design calculations attached.
Registration is not for proposed new human crematory unit(s).
Description of Facility
Below, or as an attachment to this form, provide a description of all crematory operations at the facility in sufficient detail to demonstrate the facility's eligibility for use of this air general permit and to provide a basis for tracking any future equipment or process changes at the facility. Describe all air pollutant-emitting processes and equipment at the facility, and identify any air pollution control measures or equipment used.
This is a re-registration for a B & L Cremations Systems, Inc. Phoenix II series human crematory incinerator.
The crematory is designed to burn human remains at the average incineration rate of 150 pounds per hour. The incinerator consists of primary and secondary (afterburner) chambers, each fired exclusively on propane (LPG) with a maximum total design heat input rate of 1.3 mmbtu/hr (0.3 mmbtu/hr. Primary chamber, 1.0 mmbtu/hr. Secondary chamber).
Emissions are controlled by the afterburner that maintains a minimum secondary chamber combustion zone temperature of 1600°F prior to and during combustion of material in the primary chamber. The secondary chamber is designed to insure one-second residence time at a gas temperature of 1800°F, and is equipped with a continuous temperature monitor and recorder.
The unit is equipped with an opacity monitor that adjusts the cremation process if excess opacity is measured. Opacity monitor information is attached.

DEP Form No. 62-210.920(2)(c) Effective: January 10, 2007



B&L CREMATION SYSTEMS, INC.

GENERAL PURPOSE OPACITY MONITOR

SPECIFICATIONS

LIGHT SOURCE: Pulsed visible LED

SPECTRAL RESPONSE: Between 400nm and 500 nm

ANGLE OF VIEW: Less than 4 degrees from axis

AMBIENT LIGHT: No measurable efect

MAXIMUM DISTANCE BETWEEN MONITOR AND REFLECTOR: 6 feet

MONITOR TYPE: Retro reflective using a 3" reflector

ADJUSTMENT RANGE: 0 TO 100% opacity

ACCURACY: +/- 3% of full scale

POWER: 24 VAC, less than 10 VA

OUTPUT: Relay, DPDT, 5.0 A @ 102 VAC

LED Indicator for sensitivity adjustment

TEMPERATURE: Storage, -7 degrees to 32 degrees C

Operating: -29 degrees to 66 degrees C

PHYSICAL: 8.000"H x 5.750"W x 3.375"D

ENCLOSURE: Meets NEMA 3, 4 and 12 specs



OPACITY MONITOR ADJUSTMENT PROCEDURE

The following procedure may be necessary to be performed from time to tome due to vibration on the top of the retort. This procedure is designed to be both simple and quick, and to insure the proper operation of your retort.

It is suggested that before starting, this procedure be carefully read, and if you have any questions, call the service department at B&L Cremation Systems. A service technician will be happy to answer any questions or assist you with the alignment/adjustment of your opacity monitor.

The best time to perform this procedure is on a cool retort.

Please check the cleanliness of the opacity monitor lens and reflector. Inspect the reflector for any damage, replacing it as necessary.

You will need the following tools. 6" adjustable wrench 7/16" wrench A Phillips screwdriver A small straight slot screwdriver 6' to 8' stepladder

- Step 1. Open the electrical cabinet located on your retort. Inside, locate the "C1 BLOWER" contractor. At the bottom of the contactor, from left to right, you will see a red "STOP" button. To the right of this is a blue "RESET" button. Above this is a "TEST" slot (see fig. 1).
- Step 2. Turn on the retort with the main timer set to zero. The "Cool Down" lamp should be illuminated.
- Step 4. Next, it will be necessary to get on top of the retort. Inspect the opacity monitor, locating the red alignment L.E.D. and the sensitivity adjustment (see fig. 2). The red L.E.D. should be lit, and by passing your hand in front of the lens you should be able to hear the opacity monitor click. If you are experiencing minor nuisance tripping of the opacity system, turn the sensitivity adjustment CLOCKWISE approximately 1/8 turn. This should correct the problem. Now press the round blue "RESET" button located on the "C1 BLOWER" contactor in the electrical cabinet. Your retort is now ready to operate. If, however, the red L.E.D. is not illuminated or you do not hear the clicking when you pass your hand in front of the monitor, proceed to step 5.
- Step 5: Turn the sensitivity adjustment FULLY CLOCKWISE. Loosen the two mounting bolts hold the opacity monitor. By slowly moving the opacity monitor (left or right, forward or backward), obtain the maximum brightness possible for the L.E.D. Carefully tighten one of the mounting bolts, using shims as necessary, then snug the remaining bolt. Do NOT tighten this bolt. Turn the sensitivity adjustment COUNTERCLOCKWISE until the monitor clicks. Turn the sensitivity adjustment CLOCKWISE until you hear the monitor click again, then continue CLOCKWISE an additional 1/8 turn. The opacity monitor is now correctly set. Press the round blue "RESET" button on the C1 BLOWER contactor, completing the alignment procedure. Please note: if the circuit board is black counterclockwise and clockwise are reversed. Counterclockwise will be clockwise and clockwise will be counterclockwise.

If the L.E.D. does not illuminate, or if the monitor does not click, please contact the service department at B&L Cremations Systems to further assist you.



OPACITY MONITOR ADJUSTMENT PROCEEDURE

FIGURE L'CL BLOWER"





FIGURE 2, OPACITY MONITOR



PAGE 2



7205 114TH Avenue North • Largo, Florida 33773 1-800-622-5411 • 727-541-4666 • Facsimile 727-547-0669

TEMPERATURE CONTROL SEQUENCE

A type "K" thermocouple is placed 19 - 20 ft³ downstream of the afterburner flame tip to measure temperature. The downstream distance is determined based on residence time calculations. The temperature signal is sent to the main control panel where it is received by a FUJI PYZ series temperature controller with a digital readout and a Honeywell DR4200 temperature recorder. The temperature controller controls the temperature via a motorized butterfly valve located on the afterburner inlet gas assembly. Gas demand is controlled to maintain a steady temperature. The ignition/cremation burner is interlocked to the afterburner temperature by the temperature controller set point. Combustion cannot start until temperature set point is reached. Alarm contacts in the temperature controller are utilized for over (high) temperature conditions. 100° F over set point the afterburner will be in maximum low fire and the ignition/cremation burner will shut off. The butterfly valve located on the secondary air inlet is controlled by a separate temperature output to add air to cool the system. At set point the unit will return to normal operation. An optimonitor smoke detector is placed on the stack and set at 10% opacity. If emissions occur the alarm will sound, a visual red warning lamp located on the control panel will illuminate and the primary burners will shut off. The excess air butterfly valve will open to add air to the secondary chamber to oxidize the emissions. After a five (5) minute period the unit will revert to normal operations.

Southern Environmental Sciences, Inc.

1204 North Wheeler Street □ Plant City, Florida 33563 □(813) 752-5014, Fax (813) 752-2475

January 26, 2009

Ms. Lisa Sommers Trinity Memorial cemetery, Inc. 12609 Memorial Dr. New Port Richey, FL 34655

Re: Air General Permit Registration

Human Crematory

Dear Ms. Sommers:

Attached for your review are two bound and on unbound copy the general permit registration for your human crematory. You will need to sign and date the unbound copy and send it to the following address <u>as soon as possible</u>. A check in the amount of \$100.00 must accompany the registration.

Florida Department of Environmental Protection Receipts P. O. Box 3070 Tallahassee, Florida 32315-3070

The additional copies contain your permit conditions. One copy should be kept at the crematory.

The registration becomes effective 30 days after it is received in Tallahassee and is valid for five years. If you have any questions concerning the permit registration or we can be of any further assistance to you please do not hesitate to call.

Very Truly Yours,

SOUTHERN ENVIRONMENTAL SCIENCES, INC.

Kenneth M. Roberts, QEP

Vice President

KMR/mr

AIR GENERAL PERMIT REGISTRATION

TRINITY MEMORIAL CEMETARY, INC. D/B/A TRINITY MEMORIAL GARDENS

HUMAN CREMATORY

January 26, 2009

SES Reference No. 09P54 Facility ID No. 1010365

Prepared For:

TRINITY MEMORIAL CEMETARY, INC.

12609 Memorial Dr.


New Port Richey, Florida 34655

Prepared By:

SOUTHERN ENVIRONMENTAL

SCIENCES, INC.

1204 North Wheeler Street Plant City, Florida 33566





Indirect discontinuous distributions distributions discontinuous discontinuous distributions distributions discontinuous disco

FROM:



TRINITY MEMORIAL GARDENS

12609 Memorial Drive New Port Richey, Florida 34655

Florida Dept. of Environmental Protection Receipts

P.O. Pox 3070
Tallahassee, FL 32315-3070

TO: