ANIMAL CREMATORY AIR GENERAL PERMIT REGISTRATION FORM

Part II. Notification to Permitting Office

RECEIVED

(Detach and submit to appropriate permitting office; keep copy onsite)

NOV 16 2011

Instructions: To give notice to the Department of an eligible facility's intent to use this apprecian of AIR permit, the owner or operator of the facility must detach and complete this part of the air complete MANAGEMENT Registration Form and submit it to the appropriate Department of Environmental Protection or local air pollution control program office which has permitting authority. Please type or print clearly all information, and enclose the appropriate air general permit registration processing fee pursuant to Rule 62-4.050, F.A.C. (\$100 as of the effective date of this form)

Registration Type
Check one:
 INITIAL REGISTRATION - Notification of intent to: Construct and operate a proposed new facility. Operate an existing facility not currently using an air general permit (e.g., a facility proposing to go from an air operation permit to an air general permit).
RE-REGISTRATION (for facilities currently using an air general permit) - Notification of intent to: ☐ Continue operating the facility after expiration of the current term of air general permit use. ☐ Continue operating the facility after a change of ownership. ☐ Make an equipment change requiring re-registration pursuant to Rule 62-210.310(2)(e), F.A.C., or any other change not considered an administrative correction under Rule 62-210.310(2)(d), F.A.C.
Surrender of Existing Air Operation Permit(s) - For Initial Registrations Only
If the facility currently holds one or more air operation permits, such permit(s) must be surrendered by the owner or operator upon the effective date of this air general permit. In such case, check the first box, and indicate the operation permits being surrendered. If no air operation permits are held by the facility, check the second box.
All existing air operation permits for this facility are hereby surrendered upon the effective date of this air general permit; specifically permit number(s):
No air operation permits currently exist for this facility.
General Facility Information
Facility Owner/Company Name (Name of corporation, agency, or individual owner who or which owns, leases, operates, controls, or supervises the facility.)
Pet Angel World Services (Florida) LLC
Site Name (Name, if any, of the facility site; e.g., Plant A, Metropolis Plant, etc. If more than one facility is owned, a registration form must be completed for each.)
Facility Location (Provide the physical location of the facility, not necessarily the mailing address.)
Street Address: 1941 Park Meadows Drive Suite 8
City:Ft. Myers County:Lee Zip Code:33907 – 3703
Facility Start-Up Date (Estimated start-up date of proposed new facility.) (N/A for existing facilities)

DEP Form No. 62-210.920(2)(d) Effective: January 10, 2007

3255

Owner/Authorized Representative Name and Position Title; (Person who, by signing this form below, certifies that the facility is eligible to use this air general permit.) Print Name and Title: Sharon Martinache, Regional Manager Owner/Authorized Representative Mailing Address Organization/Firm:Pet Angel World Service (Florida) LLC Street Address:6225 72nd Ave Zip Code: 33781 - 4149 City:Pinellas Park County:Pinellas Owner/Authorized Representative Telephone Numbers Telephone: 727-548-1456 Fax: Cell phone (optional): Facility Contact (If different from Owner/Authorized Representative) Name and Position Title (Plant manager or person to be contacted regarding day-to-day operations at the facility.) Print Name and Title: Facility Contact Mailing Address Organization/Firm: Street Address: City: County: Zip Code: Facility Contact Telephone Numbers Telephone: Fax: Cell phone (optional): Owner/Authorized Representative Statement This statement must be signed and dated by the person named above as owner or authorized representative I, the undersigned, am the owner or authorized representative of the owner or operator of the facility addressed in this Air General Permit Registration Form. I hereby certify, based on information and belief formed after reasonable inquiry, that the facility addressed in this registration form is eligible for use of this air general permit and that the statements made in this registration form are true, accurate and complete. Further, I agree to operate and maintain the facility described in this registration form so as to comply with all applicable standards for control of air pollutant emissions found in the statutes of the State of Florida and rules of the Department of Environmental Protection and revisions thereof. I will promptly notify the Department of any changes to the information contained in this registration form. haron Martinache 10/31/11

DEP Form No. 62-210.920(2)(d) Effective: January 10, 2007

Design Calculations If this is an initial registration for a proposed new animal crematory unit, provide design calculations to confirm a sufficient volume in the secondary chamber combustion zone to provide for at least a 1.0 second gas residence

Manufacturer's' design calculations attached.

Registration is not for proposed new animal crematory unit(s).

Description of Facility

time at 1800 degrees F.

Below, or as an attachment to this form, provide a description of all crematory operations at the facility in sufficient detail to demonstrate the facility's eligibility for use of this air general permit and to provide a basis for tracking any future equipment or process changes at the facility. Describe all air pollutant-emitting processes and equipment at the facility, and identify any air pollution control measures or equipment used.

* SEE ATTACHED E-MAILS DATED

11/28/11 & 11/22/11 As AN ADDENOUM

TO THIS REGISTRATION.

DEP Form No. 62-210.920(2)(d) Effective: January 10, 2007

CALCULATIONS FOR PRODUCTS OF COMBUSTION AND RESIDENCE TIME FOR 75 LB/hr TYPE IV WASTE. B&L SERIES CREMATORY

NATURAL GAS

A. BASIS: 1 LB WASTE

1. <u>1 lb waste X 1000 Btu/lb waste X 15 lbs air</u> = 1.5 lbs air 10,000 Btu

2. 1 lb waste X 0.10 lb combustible = 0.10 lbs of combustibles

1 lb waste

3. <u>1 lb waste X 0.85 lb H20 X 1.6*</u> = 1.36 lbs of water

1 lb waste

4. $\underline{6,500}$ Btu aux fuel** X 10.0 cu ft air/cu ft fuel = 4.64 lbs of air for aux fuel

1,050 Btu/cu ft fuel X 13.35 cu ft air/lb air @ 70f

5. $\underline{6,500}$ Btu aux fuel X 0.044 lb fuel/cu ft fuel = 0.27 lb of aux fuel

1,050 Btu/cu ft fuel

6. Sum = PRODUCTS OF COMBUSTION (POC) = 7.86 lbs POC per lb

waste @ 70f

B. RESIDENCE TIME @ 1600 F

1. <u>7.86 lbs POC/lbs waste X 51.89 cu ft / lb POC @ 1600f X 75 lbs waste / hr</u> 3600 sec/hr

= 8.49 cu ft / sec @ 1600 f = 9.0 cu ft for 1 second residence time

RESIDENCE TIME @ 1800 F

2. <u>7.86 lbs POC/lbs waste X 56.93 cu ft /lb POC @ 1800f X 75 lbs waste / hr</u> 3600 sec/hr

= 9.32cu ft / sec @ 1800f = 10.00 cu ft for 1 second residence time

* Correction multiplier for dry air and water vapor

** Fuel is Natural Gas

Referances: Incinerator institute of America.

North American Combustion Handbook Eclipse Combustion Engineering guide

C. THERMOCOUPLE PLACEMENT.

Secondary chamber operating temperature at > or = to 1600f = 9.00 cu ft from flame tip. 1800f = 10.00 cu ft from flame tip.

* ADDENDUM TO #07/0207-007 PAGE 9, DESCRIPTION OF FACILITY

Dibble, Dickson

From:

Heather Dinkel [heather.dinkel@petangelworldservices.com]

Sent:

Monday, November 28, 2011 12:13 PM

To:

Dibble, Dickson

Subject:

Page 9

Attachments:

11-28-11 Permit info Retort page 9.TIF

Mr. Dibble,

I have attached page 9. I hope it gives you the info you need to move forward.

Thanks,

Heather

Design Calculations
Design Calculations If this is an initial registration for a proposed new animal crematory unit, provide design calculations to confirm a sufficient volume in the secondary chamber combustion zone to provide for at least a 1.0 second gas residence time at 1800 degrees F.
Manufacturer's' design calculations attached.
Registration is not for proposed new animal crematory unit(s).
Description of Facility
Below, or as an attachment to this form, provide a description of all crematory operations at the facility in sufficient detail to demonstrate the facility's eligibility for use of this air general permit and to provide a basis for tracking any future equipment or process changes at the facility. Describe all air pollutant-emitting processes and equipment at the facility, and identify any air pollution control measures or equipment used.
Crawford C-10005 (5/N 1C5921B09920L5) This writ has two after burners to help with controlling pellution. There is no other measurements on the unit. as no other air pollution control in our other air pollution control in maintained by retort personnal. They maintained by retort personnal. They maintain heat so there is no smoking out of stack.

Dibble, Dickson

* ADDENDUM TO #0710207-007 PAGE 9. VESCEIPTIOD OF FACILITY

From	
1.10111	

Heather Dinkel [heather.dinkel@petangelworldservices.com]

Sent:

Tuesday, November 22, 2011 12:00 PM

To:

Dibble, Dickson

Subject:

Re: Pet Angel South Florida

Mr. Dibble,

I will absolutely get page 9 filled out and sent to you. The Crawford C500P (S/N 1CP86231286-S) was never installed in our facility. Due to purchasing the B&L Cremation Systems, Model BLI-400/75 that we are requesting permit, we decided not to move the C500p from our other location. The Crawford C-1000S (S/N ICS92180992ULS) is the only unit we currently have in our facility.

Sorry for the confusion.

Heather

On Tue, Nov 22, 2011 at 10:50 AM, Dibble, Dickson < Dickson. Dibble@dep.state.fl.us > wrote:

Good morning Heather!

Thank you so much for your very prompt reply to my request.

I am in need of some clarification and additional information.

1) Our records (Emission Unit ID# EU003) indicate there is a Crawford C-1000S (S/N ICS92180992ULS) unit at your facility, yet there is no reference to it in the registration submitted or in your e-mail below. Please help me clarify this difference. See Below:

EU003

	{		. e e distriction e e e e e e e e e e e e e e e e e e e
source management	System - Emissions Unit 1990 (1990)		
POINT	AIRS ID 0710207 STATUS		ARMINV51
SITE NAME	PET Aliget WORLD SERVICES	COUNTY	LEE
OVNER/COMP		Count	Andrea (197) and a control of the co
ovview com	,	lon & Status	
Emis Unit ID		Oz SIP Base Yr Unit 🧗	F [
Description • An	urnal Crematory preni2ndary chintos,80	5 threat, 1901the for	- -
€U Class • 🖟	Regulated Emissions Unit	n me e e e	
Type	9.07 Incinerator - Animal Crem	AIRS Desc ANIMI	AL CREMATORY PRIMARY/
Idaj Group SIC 72	Personal Services		Construction DI
Gen Robing	MVV CEMS - Method	of Compliance (ii -)	Startup DI
Manufacturer CR	AVAFORD EQUIPMENT & ENGINEERING CO.		
Model No C-	1000S	Long Term Resi	erve Shutdown DI
		tant BA 0 ;	# of VE Subtype
	I ICS92180992ULS, Includes secondary b	urner and combustion cham	ber s
		nerator	
Dwell Time	1.00 Ser Dwell Ten	nn 1300 c	Afterburner Temp 1600 F

2) Our records indicate the second unit (Emission Unit ID# EU004), a Crawford C500P (S/N 1CP86231286-S) was added, or submitted as an Air General permit equipment change registration on 7/27/2011 by Sharon Martinache and issued on 08/27/11 and is most likely the one to which you are referring in your e-mail below. See EU 004 screen capture below:

EU004

	ن المساور المساور
Final Department of Antonne and Rose and Silvery	Kiels troffestiga est
DEATH ENGINE ENGINE OF CHARLES AND CONTROL OF CONTROL O	
(#Air Resource Management System Emissions Unit	
	ARMINV51
POINT AIRS ID 0710207 STATUS A OFFICE SD	Sth: FT: MYERS
SITE NAME PET ANGEL WORLD SERVICES COUNTY	LEE
OWNER COMP PET ANGEL WORLD SERVICES LLC	
Description & Status	
Emis Unit ID: 004 Status* 🖫 Active Oz SIP Base Yi Unit 🚻	
Diescription * Aminal Crematory-primi/2ndarychmbrs.)IG.75ths:/hrOpachtill.cmp#18/	
€U Class • R Regulated Emissions Unit	
Type 9.07 Incinerator Animal Crem AIRS Desc AliMA	I, CREMATORY-PRIMORU
Maj Group SIG 72 Personal Services. Commence	Construction DI
Gen Raling Myy CEMS - Method of Compliance (II -	Startue DI
Manufacturer CRAVNOND Perman	ent-Shutdown-DI
Model No: CS00P Long Term Rese	rve Shutdown DI
# of Segment 0 A 0 # of Pollulant 0 A 0 1	#.ofVE.Sublype 0
Comment S/N 1CP86231285-S	;
Incinerator	
Dwell Time 1.00 Sec Dwell Temp 1800 F	Afterburner Temp 11:00 F
The second second is the second secon	
and the state of t	(magnetic many governor or management)
TERROPH LINESCANO	
State Principle - College Control of Control	

3) The current registration, received on 11/14/11, indicates the addition of another unit (B&L Cremation Systems, Model BLI-400/75, no S/N; see EU screen capture below), which will bring the total units at your facility to three rather than the one as listed in the registration.

Proposed Emission Unit ID# EU005

The first of the f	Kind I stroffestling colum
Companies and section to the properties of the section of the sect	وسرو استفاد المناسب المساويات المساويات المساويات المساويات المساويات
TOTAL STREET, COUNTY STREET, COUNTY CHINAST LIN C	
Bandadanajaza 32 - Greener	
कृ Air Resource Management System - Emissions Unit	
	ARMINV51
POINT AIRS ID 0710207 STATUS A OFFICE SD	Sth: FT MYERS
SITE NAME PET ANGEL WORLD SERVICES COUNT	ry, Left
OWNER COMP. PET AIIGEL WORLD SERVICES LLC	
Description & Status Descripti	
Description.* Animal Crematory-primized anythmbre. IIG. tenm M&R. opacM.79 lb-70	- Santa Caraca
EU Class Regulated Emissions Unit	AND THE RESIDENCE OF THE PARTY
	IMAL CREMATORY PRIMIZHO
The second secon	ence Construction DI
Gen Rating Myy CEMS - Method of Compliance [II]	Skyrup Et. 12/15/2011
The state of the s	manent Shutdown DI
Model No. (81.1.400.75 Long Term R	eserve Shutdown DI
# of Segment 0 A 0 1 For Pollutant BiA 0 1	≠ of VE Subtype ■
Comment SiN NOT AVAILABLE unit not constructed as of 11/14/11	
Incinerator	
Dwell Time Sec Dwell Temp F	Afferburner Temp F
المرافع الم	The second secon
	1 1.
Grandin Constant	
research till	ಷ್ಟರ್ , ಕರ್ಣವಗ್ರಾಜಕ್ರಿಸ್ ಕ್ಷ್ಮಾರ್ನಿಸಿ ಪ್ರಾತಿಗಳಿಗಳು ಪ್ರಕರ್ತಿಗೆ

The clarifying question: Does this mean you will actually have three (3) animal crematory units at this location, or was the C-1000S removed?

Please let me advise that in the future, when registering, renewing, changing ownership or wishing to make changes in equipment at registered facilities, registrants are required to provide equipment details of each and all emission units at a facility, not just the new one being added or removed. In these cases the typical information required for crematory units would be as follows:

EXISTING & already registered unit(s):

- a. Manufacturer/Make
- b. Model
- c. S/N
- d. Rated Capacity expressed in Lbs/hr (burn rate
- e. Type of fuel Natural Gas (NG), Liquid Propane (LP), diesel/fuel oil, etc.

For proposed <u>NEW facilities/units</u>, design calculations are required, as well as the above information.

I have attached a pdf copy of the current registration submittal by Ms. Martinache for your reference. The Description of Facility block on Page 9 was left blank and the information requested is required. In order for me to continue with the review and processing of your registration, I will only need an updated Page 9, Description of Facility. Ms. Martinache did include the design calculations for the new unit, so there is no need to submit those all over again.

To make this as simple as possible, if you would be so kind to download the form and print Page 9, fill it out, scan it and send it back to me as an electronic copy via e-mail and I will attach it as an addendum to the original registration.

If you have any questions, comments or concerns please e-mail or call.

Thank you and have a very Happy Thanksgiving Day Holiday.

Sincerely yours,

Dickson E. Dibble

Dickson E. Dibble, ES III

Air General Permit Program

FDEP Division of Air Resource Management Office of Permitting & Compliance Minerals & Metals Section

Tel. (850) 717-9071

FAX (850) 717-9001

GIC - #59571

Dickson.Dibble@dep.state.fl.us



Please note: Florida has a very broad public records law. Most written communications to or from state officials regarding state business are public records available to the public and media upon request. Your e-mail communications may therefore be subject to public disclosure

Please take a few minutes to share your comments on the service you received from the department by clicking on this link. DEP Customer Survey.

From: Heather Dinkel [mailto:heather.dinkel@petangelworldservices.com]

Sent: Tuesday, November 22, 2011 8:39 AM

To: Dibble, Dickson

Subject: Pet Angel South Florida

Hello Mr. Dibble,

Kristal Essenmacher said you called and requested we email you with the current equipment we have in the location we are requesting a permit for our new incinerator. Our current equipment is the Crawford model C-500P.

Please let me know if there is anything else that would fall under equipment.

Thank you,

Heather Dinkel South Florida Operation Manager 239.940.1087

BLI-400/75 - Small Batch Incinerator SPECIFICATIONS

Dimensions:

Height: 60" (70" with afterburner)

Width: 40" (52" with control panel)

Length: 84" (98" with cremation burner)

Weight: 14,000 lbs. approximate

Load Capacity Maximum:

400 lbs

Cremation Rate:

75 lbs per hour

Chamber Dimensions:

30" Wide, 42" Long, 28" High

21 Cubic Feet

Stack Height:

15 feet refractory-lined stack – 18" O.D.

Refractory/Insulation:

4 1/2" Firebrick - Walls

Castable Refractory Lining -

(Hearth & Ceiling)

1" 1900 Degree - Board Insulation

Power Requirements:

110 volts, 1-Phase, 30 AMPS

Gas Pressure:

Natural Gas:

7" W.C.

Propane:

11" W.C.

Fuel Oil:

Burner Output:

Maximum Input Rating:

850,000 BTU's per hour

Afterburner Maximum:

.500,000 BTU's per hour 100,000 BTU's per hour

Modulation Minimum: Cremation Burner:

350,000 BTU's per hour

Air Requirements:

Outside air Inlet louvers in the

room located at or below burner height, capable of passing 2,500 CFM of free air



Cremation Systems, Inc.

7205 - 114th Avenue North Largo, Florida 33773 USA 1-800-622-5411 727-541-4666 Facsimile 727-547-0669 e-mail: sales@blcremationsystems.com www.blcremationsystems.com

PROCESS DESCRIPTION

This project consists of the construction & operation of one new cremation incinerator. This facility will consist of one B & L Systems Model BLI 400/75 Animal cremator. The cremation unit will be fired on natural gas.

Deceased animal remains are manually placed into the primary chamber of the cremator. The door of the cremator is then closed. After a preheat of the afterburning chambers by the auxiliary burner, initial and supplementary combustion is provided by natural gas fired burner located in the primary chamber of the cremator. Once material combustion is initiated, the rate of the combustion is controlled by limiting both the combustion air and fuel supplied to the primary chamber through the primary burner. This process generates a highly combustible gas mixture that flows into a secondary chamber where more air is admitted to insure further oxidation of the gases. The auxiliary burner is installed in the secondary chamber of the cremator to facilitate complete combustion of all gaseous materials entering this chamber.


Once the cremation process is complete, the remains are removed from the primary chamber of the cremator.



Systems, Inc.

7205 - 114th Avenue North • Largo, Florida 33773 1-800-622-5411 • 727-541-4666 • Facsimile 727-547-0669 e-mail: blcremsys@aol.com • www.blcremationsystems.com

PROCESS FLOW DIAGRAM



World's Largest Independent Cremation Equipment Manufacturer





Systems, Inc.


7205 - 114th Avenue North • Largo, Florida 33773 1-800-622-5411 • 727-541-4666 • Facsimile 727-547-0669 e-mail: blcremsys@aol.com • www.blcremationsystems.com


TEMPERATURE CONTROL SEQUENCE

A type "K" thermocouple is placed 10 ft. down stream of the flame tip to measure temperature, the signal is sent to the main control panel where it is received by a FUJI PYZ series temperature controller with digital readout and a DR4200 temperature recorder. The FUJI PYZ series temperature controller controls the temperature via a motorized butterfly valve located on the afterburner inlet gas assembly. Gas demand is controlled by temperature to maintain a steady temperature. The ignition/cremation burner is interlocked to the afterburning temperature by the FUJI PYZ series temperature controller set point. Combustion cannot start until temperature set point is reached. Alarm contacts in the FUJI PYZ series temperature controller are utilized for over (high) temperature conditions. 100° F over set point the afterburner will be in maximum low fire and the ignition/cremation burner will shut off. The butterfly valve located on the secondary air inlet is controlled by a separate temperature out put to add air to cool the system. At set point the unit will return to normal operation. An optimonitor smoke detector is placed on the stack and set at 10% opacity if emissions occur the alarm will sound; a visual red warning lamp located on the control panel will illuminate and the primary burners will shut off. The excess air butterfly valve will open to add air to the secondary chamber to oxidize the emissions. After a five (5) minute period the unit will revert to normal operation.










ECLIPSE TURBO BLOWERS

SERIES "SMJ"



- · High efficiency
- Heavy gauge steel base and housing
- Aluminum impellers balanced statically and dynamically
- Matching air filters available
- Changeable outlet positions

Eclipse "SMJ" Blowers are centrifugal blowers that provide low pressure air for industrial combustion systems. They are also used for cooling, conveying, drying, liquid agitation, smoke abatement, vacuum cleaning, fume and dust exhausting, and other plications where air temperatures are under 220°F.


All "SMJ" Blowers are constructed of continuous welded, heavy gauge steel. The impellers are made of lightweight, high strength, riveted aluminum. Outlets on 3" and 4" models are threaded, while all others are flanged for a standard 125# ANSI companion flange. Discharge ports are sized to keep pressure losses within reasonable limits.

Blower inlet flanges are equipped with a grill that complies with OSHA regulations. If desired, the grill may be removed and the inlet bolted to a standard ANSI companion flange. Eclipse-supplied motors are standard shaft and starting torque, ball bearing, 3600 rpm units. On any blower requiring 3/4 HP or more, Eclipse recommends that polyphase motors be used.

There are four possible outlet positions. Any existing position is easily changed by removing the housing from the

blower base and remounting it in the desired position. Positions 1 through 3 can be specified for any blower. Position 4, however, requires factory approval before ordering. Position 1 is the standard assembly (bottom, horizontal) unless otherwise specified.

"SMJ" Blowers can be supplied with counterclockwise (CCW) or clockwise (CW) rotation as viewed from the motor side. CCW rotation is furnished standard unless otherwise specified.




Outlet Positions




PASHS

PID Autotune Controllers Featuring Fuzzy Logic



Operation Manual

MODERONEGURATION



Front panel size		Code
48 x 48 (1/16DIN)	-	4 .
48 X 96 (1/8 DIN)	•	Ś [.]
72 x 72 (72mm)		7]
96 x 96 (1/4 DIN)		9

Kinds of input	Code
Thermocouple (°C)	T
Thermocouple (°F)	R
RTD/Pt100 (°C)	N
RTD/Pt100 (°F)	S
4-20mA DC, 1-5V DC-	В
0-20mA DC, 0-5V DC	A

Control output 1	Code
Relay contact (reverse action)	Α
Relay contact (direct action)	B .
SSR driver (reverse action)	C
SSR driver (direct action)	D
4 to 20mA_DC (reverse action)	E ·
4 to 20mA DC (direct action)	F

Control output 2*	Code
None	Y
Relay contact (reverse action)	A
Relay contact (direct action)	В
SSR driver (reverse action)	С
SSR driver (direct action)	D
4 to 20mA DC (reverse action)	E
. 4 to 20mA DC (direct action)	F

^{*}not available on 48 x 48mm type

Additional function	Çode
Heater break alarm*	2
Process alarm &	
Heater break alarm"	. 3
None ·	4
Process alarm	5

[&]quot;not available on 48 x 48mm type


Power Supply Option	Code
24V AC/DC Supply	D'

FAUDES

- 1/4 DIN, 1/8 DIN, 72mm, 1/16 DIN and 1/32 DIN sizes available
- Choose between 3-button or 8-button operation
- · Fuzzy logic control with PID Autotune
- Universal input-T/C, RTD, current, and voltage
- 24V DC/AC supply option available
- 8 segment ramp/soak programming
- Advanced security options to prevent unauthorized changes in parameters
- NEMA 4X faceplate

GENERAL SPECIFICATIONS

·
era , es L
¥×.
· · · ·
nore



PXZ and PXW 7

POWER FAILURE PROCESSING

Memory protection:	•	Non-volatile memory hold After the recovery of power, control is started
		After the recovery of power, control is started
• • • • • • • • • • • • • • • • • • • •	•	at the value before power failure

SELF-CHECK

Method:	Watchdog timer monitors program error.	
OPERATION AND S	STORAGE CONDITIONS	

Operating temperature	-10 to 50°C	
Operating humidity	90% RH or less (non-condensing)	
Storage temperature	-20 to 60°€	

CONTROL FUNCTION

Control action	PID control with auto-tuning Fuzzy control with auto-tuning	
Proportional band (P)	0-999.9%, setting in 0.1% steps	
Integral time (I)	0-3200 sec, setting in 1 sec steps	
Differential time (D)	0-999.9 sec, setting in 1 sec steps	


Proportional action when I,D=0		
Proportional cycle	1-150 sec, setting in 1 sec steps, relay contact output, SSR/SSC drive output only	
Hysteresis width	0-50%, setting in 1% steps, 2-position action only	
Anti-reset wind up	0-100% FS, setting in 1% steps; auto-setting with auto-tuning.	
Input sampling cycle -	0.5 sec	
Control cycle	0:5 seç	

CONTROL FUNCTION (DUAL OUTPUT TYPE) (HEATING/COOLING TYPE)

P x 1/2 (P= 0-999.9%)
Heating proportional band
x cooling proportional band coefficient
Cooling proportional band coefficient 0-99.9
0:2- position action
0:3200 sec for heating and cooling
0-999.9 sec for heating and cooling

P,I,D= 0:2- position action (without dead band) for heating and cooling

I.D= 0:Proportional acti	on
Proportional cycle	1-150 sec; relay contact output, SSR/SSC drive output only
Hysteresis width	2-position action for heating and cooling: 0.5% FS 2-position action for cooling: 0.5% FS
Anti-reset wind-up	0-100% FS, setting in 1% steps, auto setting with auto tuning
Overlap/dead band	±50% of heating proportional band
Input sampling cycle .	0.5 sec
Control cycle	0.5 sec



PXW and PXZ 5





Inflantian final f